



The LG RESU16H Prime Battery

Residential Energy Storage Unit

January 2021

What Are We Going to Talk About?



Whole solution offering



Product overview and availability



Technical point of view



Troubleshooting

In the EDGE Academy:



Recording of the webinar



Addendum



FAQs

A single unit
which manages
PV, household
consumption,
and battery
power



Optimized installation with Wave-HD technology



SolarEdge Storage Solution Offerings



or



+



or



StorEdge Single Phase Inverters with HD-Wave Technology

- 2kW – 6kW
- Single and multi-inverter
- AC coupling to SE and non-SE inverter
- Supported FW 4.13
- Support for 2 batteries per inverter
*e/o June - 21

HD-Wave with external SESTI

LG Energy Solutions Batteries

- Gen 2 - RESU
- Gen 3 - RESU Prime

SolarEdge Energy Bank *e/o August - 21

- High efficiency
- Power scale-up
- Wireless installation
- Floor/Wall mount
- NMC 10kWh, 5kW

Adhere to the LG's Manual Instructions





RESU10H AND RESU16H Prime Battery


RESU 10H Prime - Specifications

Dimensions



Weight

351lb (159 kg)




RESU 16H Prime - Specifications

Dimensions



Weight

351lb (159 kg)





Technical Point of View

RESU10H Prime

Electrical Characteristics	
Usable Energy ¹⁾	9.6 kWh @77F (25 C)
Usable Energy (including min.SoE) ¹⁾	9.12 kWh @77F (25 C)
Voltage Range - Charge	420 ~ 450 VDC
Voltage Range - Discharge	350 ~ 410 VDC
Max. Charge/Discharge Current	14.3A@350V
Max. Charge/Discharge Power	5kW
Peak Current (only discharging)	20A for 10 sec.
Communication Interface	RS485/CAN
DC Protection	Circuit Breaker, Fuse, DCDC converter
Connection Method	Spring Type Connector
User interface	LEDs for Normal and Fault operation
Protection Features	Over Voltage / Over Current/ Short circuit/ Reverse Polarity
Scalability (Total Energy, Max. Charge/Discharge Power)	Max. 2 in parallel (19.2 kWh @77 F (25 C),

1) DOD 100%. DC/DC converter one way efficiency 97.5%. Ambient 77 F (25 C)

2) Peak Current excludes repeated short duration (less than 10 sec. of current pattern)

RESU16H Prime

Electrical Characteristics	
Usable Energy ¹⁾	16 kWh @77F (25 C)
Usable Energy (including min.SoE) ¹⁾	15.2 kWh @77F (25 C)
Voltage Range - Charge	420 ~ 450 VDC
Voltage Range - Discharge	350 ~ 410 VDC
Max. Charge/Discharge Current	20A@350V
Max. Charge/Discharge Power	5kW
Peak Current (only discharging)	32.8A for 10 sec.
Communication Interface	RS485/CAN
DC Protection	Circuit Breaker, Fuse, DCDC converter
Connection Method	Spring Type Connector
User interface	LEDs for Normal and Fault operation
Protection Features	Over Voltage / Over Current/ Short circuit/ Reverse Polarity
Scalability (Total Energy, Max. Charge/Discharge Power)	Max. 2 in parallel (32.0 kWh @77 F (25 C)

1) DOD 100%. DC/DC converter one way efficiency 97.5%. Ambient 77 F (25 C)

2) Peak Current excludes repeated short duration (less than 10 sec. of current pattern)

Operating Conditions

Operating Conditions	RESU10	RESU16
Installation Location	Indoor/Outdoor, Floor standing, Wall mounted	Indoor / Outdoor, Stand only
Operating Temperature - Charge	14 to 122°F (-10 to 50°C)	
Operating Temperature - Discharge	-4 ~ 122 F (20 ~ 50 C)	
Operating Temperature (Recommended)	59 to 86°F (15 to 30°C)	
Storage Temperature	<ul style="list-style-type: none"> ■ -22 to 140°F (-30 to 60°C), acceptable for 7 days in total ■ -4 to 113°F (-20 to 45°C), acceptable for the first 6 months ■ -4 to 86°F (-20 to 30°C), acceptable for 7 to 12 months 	
Humidity	5% to 95%	
Altitude	Max. 6,562ft (2,000m)	
Cooling Strategy	Natural Convection	

LG ES Warranty



- LG Chem RESU Prime warranty
70% capacity retention
(vs. 60% for Gen-2)
 - After 10 years or 50MWh energy throughput (vs. 27.4MWh for Gen-2)

Certification		
Safety	Cell	Battery Pack
	UL1642	UL1973 / CE / RCM / TUV (IEC 62619)
Emissions		FCC
Hazardous Materials Classification		Class 9
Transportation		UN38.3 (UNDOT)
Ingress Rating		IP55

Safety

- Vast experience based on know how from RESU7H and RESU10H
- Safety features
 - Under voltage, over voltage, over current protection
 - Enhanced temperature sensing
 - Advanced over charge protection mechanism
 - Enhanced internal monitoring in all battery operation modes
- Certified to all required safety standards
 - Ready for UL9540A certification




Installing the RESU10H / RESU16H Prime Battery


Installation Video for RESU Prime




What's in the Box?




Battery
Module A&B




Battery
Control Unit




Module Connect
Plate Module



Support
BRKT (x2)



Standing Bracket
1 & 2




Spacer
(x2)




M6 Flange
Bolt (x18)



M5 x L200 Long
Flange Bolt (x6)





3/4"-1"
Adapter
(x2)



Cap (x2)



Cable
ties




Manual



Drill
template

Clearance




Note


An external DC isolator may be installed within the clearance zone. Minimum clearances may be greater according to local regulations.

Installation of the Battery

1. Mark the locations for drilling holes






2. Mark the locations for drilling holes





Be careful not to damage the aluminum foil attached on the bottom of Module connect plate during handling or by anchoring (DO NOT anchor).

Lifting the Battery - Handling Position


Control Unit




Battery Modules



Battery Module
(1 installer)




Battery Module
(2 installers)




Installation of the Battery

3. Fix the Standing bracket 1 on the wall




4. Place Battery Module A on the front side of the Module Connect plate




Installation of the Battery

5. Place Battery Module B on the rear side of the Module Connect plate




Top View

Battery Module A




Battery Module B

6. Assemble Module Support BRKTs using 6 bolts each




Installation of the Battery


7. Place the spacers on the position marked with label on Battery Modules



Do not remove this label before the wiring




8. Place the Battery Control Unit on top of the spacers, and align with the Battery Module





Installation of the Battery


9. Connect the power and sensor connectors on the right and left sides (2 each)




TPA
(Terminal Position Assurance)



10. Check the operation of the battery pack



Hold and turn the handle counterclockwise to open the front cover



Turn on the circuit breaker switch and close the front cover



- OK - LED power indicator will turn on
 - Fault - LED indicator will blink (60 seconds later)
- Turn off the Circuit Breaker switch

LED Indicators



Power on - This LED indicator stays on while the battery pack is on



Charging - This LED indicator stays on while the battery pack is charging




Discharging - This LED indicator stays on while the battery pack is discharging



Fault - This LED indicator stays on when the battery pack is in a warning state


Installation of the Battery

11. Remove the spacers one by one, by lifting each side of the Battery Control Unit




Be careful not to pull on the cables by lifting the Battery Control Unit too high. Doing so may cause damage to the cables or cause the unit to disconnect.

12. Realign the Battery Control Unit




Installation of the Battery

13. Loosen 4 bolts and remove the Top Cover




14. Tighten six (6) long flange bolts with a torque of 5N.m




After assembly, check again that all 6 bolts are tightened.

Installation of the Battery

15. Move the battery pack to set the right position for assembly of the Standing bracket




16. Assemble Standing Bracket #2 (flat) using six (6) M6 bolts to fix the pack onto the wall




Installation of the Battery

17. Re-attach the top cover




18. Open the front cover




Installation of the Battery

21. Assemble the adapter or cap according to regional regulations. Then insert the power and communication cables through the holes from outside of the pack



Arrange the internal cable as required to avoid blocking the holes for external cables

22. Connect the cables according to their application



Section A: Inverter communication ports including CAN/RS485 and enable lines

Section B: DIP switch for setting communication termination resistor

Section C: DIP switch for setting primary/secondary packs

Section D: Do not connect the internal communication ports


Section E: Battery power ports including positive/negative pole and ground (POS: power terminal plus, NEG: power terminal minus, GND: ground)

Common connection


LG Prime	SESTI-S4 Battery Control	StorEdge HD-Wave RS485 Terminal Board
Enable 12V	En	EN+ (pin 7)
ENABLE GND	G	RS485-2 G
RS485 A+	A+	RS485-2 A
RS485 B-	B-	RS485-2 B

Installation of the Battery

23. Arrange the power cables and communication cables separately using cable ties




24. Connect the power conductors
Connect the RS485+En communication conductors




Connecting the Battery

DC cable connection




Hole #1
Power cable



DC+ DC- ⊕


Inverter




Battery
Out

Connecting the battery and the StorEdge Interface

Communication cable




DC cable connection




Installation of the Battery

25. Re-attach the Front Protection Cover with M5 PH bolt 6ea



1


Front Protection Cover




2

M5 PH Bolt 6ea

26. Close the front cover



1



2

Hold the handle and turn it clockwise

Commissioning the Battery

- The LG Prime batteries are expected to be automatically detected
- Turn on the system
 - Turn on the AC to the inverter
 - Turn on the battery by turning on the battery CB
- Connect to the inverter via SetApp and verify the battery appears on the status screen

The screenshot displays the solar edge mobile application interface during the commissioning phase. The top header shows the solar edge logo and the system ID SN 7306937D-89. Below this, there are three main sections: Export Meter, Import Meter, and Battery. Each section provides details such as Modbus ID, status, power, and energy. The Battery section indicates it is connected and shows a state of 'Idle'.

Export Meter		
SN 606549987		
RS485-2 Modbus ID #2	Status	OK
Power	Energy	1.72 MWh
5.75 kW		

Import Meter		
SN 606549987		
RS485-2 Modbus ID #2	Status	OK
Power	Energy	25.86 kWh
0 W		


Battery		
StorEdge SN 2012221003		
Communication	Type	
Connected	LG_RESU16H	
State	Power	SOE
Idle	0 W	100.00%

Commissioning

Commissioning the Battery

- If the automatic detection of the LG Battery fails
 - Perform AC cycle to the inverter
 - Connect to the Inverter via SetApp again
 - Verify the battery appears in the RS485 menu.

To access the menu:
Commissioning > Site
Communication > RS485-1/2 >
Protocol > Modbus (Multi-Device)



The screenshot shows the solar edge mobile application interface for RS485-2 configuration. The top bar displays the solar edge logo and the serial number SN 7306937D-89. Below the title 'RS485-2', there is a list of configuration items, each with a right-pointing chevron icon:

Item	Value	Action
Protocol	Modbus (Multi-Device)	>
Meter 1	Export+Import (E+I)	>
Battery 1	16.04 kWh	>
Add Modbus Device		>

Commissioning the Battery

- **Conduct battery self test**
Commissioning > Maintenance >
Diagnostics > Self-Test > Battery
Self-Test > Run Test
- **Chose StorEdge application**
Power Control > Energy Manager >
Energy Control > MSC

Rollout Schedule



Rollout Schedule

- Minimum Firmware Version needed: **4.13.xx**
- 4.13.xx to be in SetApp, available to any installer by
 - StorEdge Single Phase Inverter with HD-Wave Technology → **Now!**
 - Single Phase Inverters with HD-Wave Technology and external StorEdge Interface → **end of June**



A photograph of two hands reaching up towards a bright sun in a blue sky with scattered white clouds. The sun is positioned between the two hands, creating a lens flare effect. The background shows a green landscape with a body of water and distant hills.

Troubleshooting

Battery Not Auto Detected

Step 1

Make sure the battery is connected to the inverter and turned on

Step 2

Manually configure the battery via the SetApp application:

Commissioning > Site Communication > RS485-1/2 > Protocol > Modbus (Multi-Device)


Return to the previous screen > Add Modbus Device > Battery

Verify the battery information by selecting:
Battery 1 > Battery Information


Step 3

If battery is still not detected, please contact SolarEdge support

If the Battery LED Power Indicator is OFF



If the LED Power Indicator is ON, but the Battery isn't Charging or Discharging



Thank You!

Cautionary Note Regarding Market Data & Industry Forecasts

This power point presentation contains market data and industry forecasts from certain third-party sources. This information is based on industry surveys and the preparer's expertise in the industry and there can be no assurance that any such market data is accurate or that any such industry forecasts will be achieved. Although we have not independently verified the accuracy of such market data and industry forecasts, we believe that the market data is reliable and that the industry forecasts are reasonable.

Rev: 05/2020/ROW

Version #: V.1.0

solar**edge**